HPRT

Quick Start Guide

TP808

Xiamen Hanin Electronic Technology Co.,Ltd

ADD: Room 305A,Angye Building,Pioneering Park,
        Torch High-tech Zone,Xiamen,China.
TEL: +86-(0)592-5885993
FAX: +86-(0)592-5885992
WEB: www.hprt.com

Packing List

Printer	USB Cable	Power Cord
Serial Cable	Power Adapter	Roll Paper
CD	Quick Start Guide	

Note: The power adapter and power cord vary by local or region.

Appearance and Components

■ **Front**

Printer Cover
Control Panel
Cover Open Button
LCD Panel
Feed button
Power button

■ **Rear**

Ethernet interface
USB interface
Serial interface
Power supply interface
Cash drawer interface

■ **Inside**

Paper Installation (Upward Paper-out Direction)

1.Press the cover open button to open the printer cover.

2.In the correct direction of the roll paper,install the roll paper.

Thermosensitive layer
○   ✕

3.Pull out some roll paper, and close the printer cover.

4.Tear the extra paper in the direction of printer.


3.Pull out some roll paper, and close the printer cover.


4.Tear the extra paper in the direction of printer.

Paper Installation
(Forward Paper-out Direction)

1.Remove the bottom cover and rear cover, after removing, the location of these two covers can be swapped and re-installed, as below showed. Remove the used roll paper core, if any.

2.In the correct direction of the roll paper,install the roll paper.

Thermosensitive layer

○   ✕

Power Supply

1.Connect power adapter with printer.

2.Connect power adapter with power cord.

3.Plug the other side of power cord into the socket outlet.

❶

Power Adapter

❷

Power Cord

❸